



RELEASE NOTE FOR THE FAST ETHERLINK® XL PCI 10/100 ETHERNET USER GUIDE

For PowerPC™ Microprocessor-based Systems

P/N 09-1058-000/November 1996

Important Installation Instructions

The following table lists the acceptable PCI slots for various PowerPC microprocessor-based system units.

PowerPC System Unit	Acceptable PCI Slots
RS/6000 7024 Models E20/E30	Slots 3P, 4P, 5P, or 6P only
RS/6000 7025 Model F30	Slots 4P, 5P, 6P, or 7P only
24/E2 and 24/E3	Slots 3P, 4P, 5P, or 6P only
25/F3	Slots 4P, 5P, 6P, or 7P only
All other PowerPC microprocessor-based systems	Any slot